

VT/HP Keyboard Map

for Common MC50

Booting Procedures

Boot Type	Procedure
Soft Reset	Reset Button
Hard Reset	Right Scan Button + Power Button + Reset Button

Local Terminal Functions

Local Function	Key Sequence
Program Information	N/A
Diagnostics	N/A
Keyclicks On/Off	N/A
Quiet Mode On/Off	N/A
Terminal Configuration	N/A
Host Profiles	N/A
VT/HP Terminal Setup	N/A
Close Session	N/A
Previous Session	N/A
Next Session	N/A
Caps Lock	N/A
View Mode On/Off	<Orange> <Shift>
Scroll Left	N/A
Scroll Right	<Blue> <J>
Scroll Up	<Blue> <L>
Scroll Down	<Blue> <I>

*Alpha Mode

VT/HP Keyboard Map

for Common MC50

VT-100 Emulation Keys

VT-100 Key	Key Sequence
Return	<Enter>
Backspace	<Orange> <Tab>
Tab	<Tab>
Up Arrow	<Blue> <I>
Left Arrow	<Blue> <M>
ESC	N/A
BS	<Backspace>
LF	N/A
Hard Terminal Reset	N/A

VT-100 Key	Key Sequence
Enter	<Enter>
Backspace(Delete)**	<Backspace>
Backtab	<Orange> <Tab>
Down Arrow	<Blue> <J>
Right Arrow	<Blue> <L>
PF1	N/A
PF2	N/A
PF3	N/A
PF4	N/A

VT-220 Emulation Keys

VT-220 Key	Key Sequence
Return	<Enter>
Backspace	<Backspace>
Tab	<Tab>
Up Arrow	<Orange> <I>
Left Arrow	<Orange> <J>
Hard Terminal Reset	N/A
Find	N/A
Insert Here	N/A
Prev Screen	N/A
PF1	N/A
PF2	N/A
PF3	N/A
PF4	N/A
BREAK ¹	N/A
F6	N/A
F7	N/A
F8	N/A
F9	N/A
F10	N/A

VT-220 Key	Key Sequence
Enter	<Enter>
Backspace(Delete)**	<Backspace>
Backtab	<Orange> <Tab>
Down Arrow	<Orange> <M>
Right Arrow	<Orange> <L>
Soft Terminal Reset	N/A
Select	N/A
Remove	N/A
Next Screen	N/A
F11	N/A
F12	N/A
F13	N/A
F14	N/A
F15/Help	N/A
F16/Do	N/A
F17	N/A
F18	N/A
F19	N/A
F20	N/A

*Alpha Mode

** See Wavelink Knowledge Base article #528

<http://www.wavelink.com/support.aspx>

¹ The BREAK key is currently not available.

VT/HP Keyboard Map

for Common MC50

HP Emulation Keys²

HP Key	Key Sequence
Return	<Enter>
Backspace	<Backspace>
Tab	<Tab>
Up Arrow	<Blue> <I>
Left Arrow	<Blue> <J>
Insert Line	N/A
Insert Char	N/A
Hard Terminal Reset	N/A
Prev	N/A
Clear Line	N/A
Insert Char with wrap	N/A
Scroll Down	N/A
F1	N/A
F2	N/A
F3	N/A
F4	N/A
User Key Menu	N/A

*Alpha Mode

HP Key	Key Sequence
Enter	<Enter>
Backspace(Delete)**	<Backspace>
Backtab	<Orange> <Tab>
Down Arrow	<Blue> <M>
Right Arrow	<Blue> <L>
Delete Line	N/A
Delete Char	N/A
Soft Terminal Reset	N/A
Next	N/A
Clear Display	N/A
Delete Char with wrap	N/A
Scroll Up	N/A
F5	N/A
F6	N/A
F7	N/A
F8	N/A
System Modes Menu	N/A

** See Wavelink Knowledge Base article #528

<http://www.wavelink.com/support.aspx>

² The BREAK and STOP keys are currently not available.

VT/HP Keyboard Map

for Common MC50

VT/HP Character Map

Char	Key Sequence
^@	N/A
^A	N/A
^B	N/A
^C	N/A
^D	N/A
^E	N/A
^F	N/A
^G	N/A
^H	N/A
^I	N/A
^J	N/A
^K	N/A
^L	N/A
^M	N/A
^N	N/A
^O	N/A
^P	N/A
^Q	N/A
^R	N/A
^S	N/A
^T	N/A
^U	N/A
^V	N/A
^W	N/A
^X	N/A
^Y	N/A
^Z	N/A
ESC	N/A
^\	N/A
^]	N/A
^^	N/A
^_	N/A
Space	<Space>
!	<Orange> <X>
“	<Orange> <V>
#	<Orange> <Enter>
\$	<Orange> <W>
%	<Orange> <R>
&	<Orange> <Q>
'	<Orange> <C>
(<Orange> <A>
)	<Orange> <S>
*	<Orange> <Star>

Char	Key Sequence
+	N/A
,	<,>
-	<Orange> <H>
.	<.>
/	<Orange> <T>
0	<Orange> <.>
1	<Orange> <U>
2	<Orange> <I>
3	<Orange> <O>
4	<Orange> <J>
5	<Orange> <K>
6	<Orange> <L>
7	<Orange> <N>
8	<Orange> <M>
9	<Orange> <,>
:	<Orange> <F>
;	N/A
<	N/A
=	<Orange>
>	N/A
?	<Orange> <Z>
@	<Orange> <E>
A	<Shift> <A>
B	<Shift>
C	<Shift> <C>
D	<Shift> <D>
E	<Shift> <E>
F	<Shift> <F>
G	<Shift> <G>
H	<Shift> <H>
I	<Shift> <I>
J	<Shift> <J>
K	<Shift> <K>
L	<Shift> <L>
M	<Shift> <M>
N	<Shift> <N>
O	<Shift> <O>
P	<Shift> <P>
Q	<Shift> <Q>
R	<Shift> <R>
S	<Shift> <S>
T	<Shift> <T>
U	<Shift> <U>

Char	Key Sequence
V	<Shift> <V>
W	<Shift> <W>
X	<Shift> <X>
Y	<Shift> <Y>
Z	<Shift> <Z>
[N/A
\	N/A
]	N/A
^	N/A
_	<Orange> <D>
`	N/A
a	<A>
b	
c	<C>
d	<D>
e	<E>
f	<F>
g	<G>
h	<H>
I	<I>
j	<J>
k	<K>
l	<L>
m	<M>
n	<N>
o	<O>
p	<P>
q	<Q>
r	<R>
s	<S>
t	<T>
u	<U>
v	<V>
w	<W>
x	<X>
y	<Y>
z	<Z>
{	N/A
	N/A
}	N/A
~	N/A

* Alpha Mode